


Electronic lock with digit codes

- ✓ Version for single and multiple users, for private and public use (switch via master key, sold separately)
- ✓ Simple operation and high security thanks to numerical code (1-6 digits for single users or 4 digits for multiple users)
- ✓ For door thicknesses from 1 to 22 mm
- ✓ Emergency opening with a master key
- ✓ Low battery warning signal
- ✓ Battery required: (2xAAA) not included in scope of delivery




Details

Locking path
12 → 3 o'clock








Locking path
12 → 9 o'clock



Mounting options



Technical drawings



Article	Description	Locking path	Colour	Item-No.
NOKY Solo pro, right	Electronic lever lock set for wooden and metal furniture, including bolt (L: 45 mm) and fixing screw, ABS plastic, CE, IP55, batteries (2x AAA) not included	12-9 o'clock	Black	121 137016
NOKY Solo pro, left		12-3 o'clock	Black	121 137009
NOKY Solo pro, vertical		3-12 o'clock	Black	121 137023
NOKY Solo master key		-	Blue	113 122764
NOKY Solo backplate	Installation in doors with panel thickness 0,8-1,2 mm, ABS plastic, including battery cover	-	Black	121 124094
NOKY Solo backplate	Installation in doors with panel thickness 18-22 mm, ABS plastic, including battery cover	-	Black	121 123058
NOKY Solo battery cover	For NOKY Solo P/S/Pro, plastic ABS, incl. 1x battery cover screw	-	Black	121 124101